

## Programming the Scanner

The scanner is shipped from the factory programmed to a set of default conditions noted in this guide by an asterisk that appears before the brief definition. Since each host system is unique, the scanner has to be configured to match your host system requirements.

1. Connect the scanner to the host system or power source.  
(Refer to the Installation and User's Guide MLPN 2365.)
2. Scan the ENTER/EXIT PROGRAM MODE bar code.  
(The unit will beep three times.)



3. Scan by positioning the output window within two inches of each code. (When the first menu selection has been scanned, the laser will stay on until the ENTER/EXIT PROGRAM MODE code is scanned again. If no scanning occurs for 30 seconds while the scanner is in program mode, the unit will beep three times and all changes made will be lost. If this occurs, return to Step 1.)
4. Upon completing the scanning of the appropriate configuration options, scan the ENTER/EXIT PROGRAM MODE bar code again. (The new options will be saved and the scanner is ready for normal operation.)

**Note:** While in program mode, the scanner will make a "razz" sound when:

- the bar code it is scanning is not a program mode code type;
- the feature is not currently supported in the firmware;
- the feature is not supported on the scanner's hardware configuration.

The sound serves as an audible indication that the scanner will not support that feature.

### Recall Defaults



## Enter Program Mode

---

### \*\*Ability to Enter Program Mode After Any Scan



When this option is selected, programming can be entered by scanning the ENTER/EXIT PROGRAM MODE bar code after power up or during normal scanning operation.

### Enter Program Mode Only on First Scan



When this option is selected, the scanner will only enter program mode after power-up. Scan the ENTER/EXIT PROGRAM MODE bar code immediately after the scanner first receives power. This option prevents the scanner from accidentally entering program mode during normal scanning operation.

## Recall Defaults

---

If during programming of the scanner, there is a need to return to the original factory settings, scan the RECALL DEFAULTS bar code. Any settings selected during that session or a previous session will be lost.

### Recall Defaults

